

# HC20 Television - Evaluation Set-Up

## Things You Will Need

- 1) Items supplied in the evaluation package:
  - a) Television (with attached HC20 unit) and these accessories:
    - TV power cord
    - HC20 power adapter
    - TV IR Remote
    - TV Instruction Manual
  - b) Curbell Gen4 Pillow Speaker
- 2) Access to
  - TV Content via Cable or Antenna
  - AC Power Outlets (2)

## Step 1 – Set Up TV

- a) Connect TV Power Cord to TV and AC outlet
- b) Connect TV to Cable TV or Antenna
- c) Verify basic TV operation using TV's IR remote (on/off, volume, channels, etc.)
- d) Auto tune TV Channels (using IR remote; see TV instruction manual)

## Step 2 – Enable Pillow Speaker Control

- a) Locate HC20 unit (attached to TV)
- b) Insert Pillow Speaker Phono Plug into HC20
- c) Connect HC20 power adapter to HC20 and AC outlet

The TV is now controlled by the pillow-speaker! You can manually turn TV's built-in speakers on and off by pressing the switch on the back of the TV. Call 541-686-2296 with questions.

